


165 Series Hob - Exploded Drawing



165 Series Parts List

DRW No.	PART CODE	DESCRIPTION
1	SG925.BK	Glass Lid, series 165 Hob, BK
2	SPCC2003.BK	Hinge, glass lid 2004 style
3	SPCC0700.EN	Support, Pan, Individual - rapid
4	SPCC0833	Burner Cap, SR, Rapid
5	SPCC0831	Flamespreader, SR, Rapid
6	SMAO1985.BK/SS	Assy, hobtop, Series 165
7	SPCC0814	Stud, fixing, burner cup
8	SPCX0339	Washer, 4bs red fibre
9	SPCX0101.BK	Screw (for lid hinge)
10	SPCX0178.BK	Washer, 2ba black fibre (for lid hinge screw)
11	SPCC1132	Thermocouple, 450mm
14	SPCC1392	Generator, Spark, 12v
16	SPCC1498	Clip, fixing, electrode
17	SPCC1453	Electrode, spark 300mm
19	SPCC1455	Electrode, spark 600mm
20	SPWK0018	Wire Kit, 12v, ignition
21	SMAC1233	Tap/Manifold Assy
	◆ SPCC0733	Tap, Burn (0.34) semi burner
	◆ SPCC0734	Tap, Grill (0.45) rapid burner
24	SPCC1130	Thermocouple, 250mm
26	SPCX0163	Locknut, M6 brass coarse thread
27	SPCX0121	Screw, M4x40 Pan Pozi
28	SMCC9305	Bracket, worktop, fixing, top line hob
30	SPCX0346	S/A EDPM Sponge washer
31	SPCX0391	Bump Stop, push fit
32	SPCC0619.BK	Knob, control BK LAM
33	SPCC0811	Flamespreader, SR, Semi
34	SPCC0813	Burner Cap, SR, Semi
35	SPCC0815	Screw, fixing, burner cap
36	SPCC0699.EN	Support, Pan, Individual - aux/semi
	SMAC9310.BK	Surround trim, series 165 vertical hob
	SPCC1499	Gasket, electrode
	SPCC1272	Instructions, user, topline hobs, Multi